

The **SignVideo** Firewire A/B Switch

Operations Manual

Copyright © 2002 by Sign video Ltd.

HOOK UP

All connections are 6 pin firewire for maximum ieee-1394 compatibility (for connections to 4 pin firewire typically found on cameras, use a 6 pin to 4 pin firewire cable). Connect the two cables you wish to switch between to the A and B terminals on the back of the unit. Connect the other cable to the DV terminal on the back of the unit.

Example: To interconnect a DV camcorder, DV video deck and computer with a non-linear edit system so that you can select between camcorder and deck do the following:

1. Connect a firewire cable between the camcorder and the A terminal on the back of the A/B switch.
2. Connect a firewire cable between the deck and the B terminal on the back of the A/B switch.
3. Connect a firewire cable between the computer and the DV terminal on the back of the A/B switch.

OPERATION

Switch between two firewire (ieee-1394) connections using the push button on the front panel. Note that the sign video firewire switch is a passive device and may or may not work to switch live signals, depending on your equipment and how it is hooked up.

Switch Type

Mechanical, break before make.

ONE YEAR LIMITED WARRANTY

Sign video Ltd. warrants this product (including accompanying accessories) and all parts thereof, except as set forth below, for a period of one year from the original date of purchase. Should the product be found to be defective, Sign Video Ltd. will repair or replace the product at no charge.

To obtain warranty service telephone one of the numbers below or log on www.signvideo.com to obtain the current telephone number for warranty repair.

The duration of any implied warranties is limited to the duration of the express warranty herein. This warranty does not cover cosmetic damage or damage due to acts of god, accident, misuse, abuse, alteration, negligence, improper installation, tampering, criminal acts, negligence, lack of reasonable care, or if serviced or repaired by anyone other than Sign video Ltd. or a repair facility authorized by Sign video Ltd.

Sign Video Ltd. shall not be liable for any loss of use, or incidental or consequential damages resulting from the use of this product or the failure or inoperability of this product in any respect, including from any cause whatsoever, or from breach of any express or implied warranty. In no event shall Sign video Ltd. be liable for any amount in excess of the purchase price paid for the product, except to the extent prohibited by applicable law.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or permit limitations on how long an implied warranty lasts, so these exclusions and limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Sign Video Ltd. (800) 373-8910 (503) 236-0000
www.signvideo.com